

#### STRICTLYTOOLBOXES.com

888-289-1952




#### **1. OPEN CARTON, REMOVE FROM PALLET**

Cut all straps with the BOX CUTTER, then lift the cardboard packaging off the side locker. Remove side locker from pallet.




#### 2. (OPTIONAL) REVERSE HANGER IF INSTALLING RIGHT SIDE LOCKER

By default, the door and hanger are configured as a left side locker. If you are installing the side locker to the right side of the toolbox, you will need to reverse the hanger, then later reverse the door towards the end of this guide. First you will need to remove the hanger from the right panel, unfasten each bolt with washer. Use the existing **WASHERS** and **M6x12 HEX BOLTS** to fasten the **HANGER** to the left side locker panel that faces the right side of the tool box.



### 3. INSTALL THE EVA LINER, REMOVE SHELVES AND DRAWERS

Place both **LINERS** on the side with the hanger, near the bottom of the side locker. Remove all shelves and drawers from inside of the side locker to prepare for a later step.



#### 4. (OPTIONAL) INSTALL SPRING LOADED CASTERS

If part of your order, you will need to install the spring loaded casters, which allow you to load the side locker beyond 250 lbs.

Lay the side locker flat on a soft mat, position the two **SPRING LOADED CASTERS** on the bottom of the locker, outer side. Insert the included **HEX BOLTS** through **WASHERS**, then through the **CASTERS**. Tighten securely to the weld nuts.




LOADED CASTER






R 15MM WRENCH




#### 5. HANG SIDE LOCKER

(FOR CASTER)


Hang the side locker off the top edge of the roller cabinet.





#### 7. INSTALL CONNECTION CHANNEL

Underneath the tool box, locate the weld nuts that will fasten the bottom of the side locker to the roller cabinet using the connection channel. Thread 4 **M6x20 HEX BOLTS** into each of the weld nuts, fasten with a **xxMM WRENCH**. You may now replace all shelves and drawers.




#### 8. (RIGHT SIDE LOCKER) REMOVE DOOR TO REVERSE

If you have installed the side locker to the right side of the roller cabinet, you will need to reverse the door. Remove all **M4x12 COUNTERSUNK SCREWS** from the left door hinge, set aside, remove the door. Remove each magnet from the right frame then insert into each slot on the left frame.



DOOR MAGNET




### 9. (RIGHT SIDE LOCKER) REVERSE LOCK BAR AND FLIP DOOR


Remove the 4 screws that fasten the lock bar to the door.

Turn the lock bar upside down so the long side is on the top and the short side is on the bottom. Fasten lock bar in place with the existing screws.

Flip the door upside down, then fasten the hinge to the right side of the frame with the existing **M4x12 COUNTERSUNK SCREWS.** 







# STRICTLYTOOLBOXES.com

DIRECT LINE: 352.672.6566 FAX: 352.226.8579 EMAIL: sales@strictlytoolboxes.com

HOURS: MON-THU 9:00am - 6:00pm EST. FRI 9:00am - 5:00pm EST.

#### © 2017 Strictly E-Commerce All Rights Reserved.

## 888-289-1952

ADDRESS: Strictly Tool Boxes 4820 NE 49th Ave Gainesville, FL 32609